







	NRPN (Hex)								
Mix CH	On/off	Pan	Dly on	Dly ms	Dly Mix	Phase	Att	Eq. on	Ins. On
Aux 1	061E	Null	12B2	12EE	Null	Null	19D2	136C	0C34
Aux 2	061F	Null	12B3	12EF	Null	Null	19D3	136D	0C35
Aux 3	0620	Null	12B4	12F0	Null	Null	19D4	136E	0C36
Aux 4	0621	Null	12B5	12F1	Null	Null	19D5	136F	0C37
Aux 5	0622	Null	12B6	12F2	Null	Null	19D6	1370	0C38
Aux 6	0623	Null	12B7	12F3	Null	Null	19D7	1371	0C39
Aux 7	0624	Null	12B8	12F4	Null	Null	19D8	1372	0C3A
Aux 8	0625	Null	12B9	12F5	Null	Null	19D9	1373	0C3B
Bus 1L	0616	Null	12AA	12C8	Null	Null	19CA	1364	0C2C
Bus 1R	0616	Null	12AA	12C9	Null	Null	19CA	1364	0C2C
Bus 2L	0617	Null	12AB	12CA	Null	Null	19CB	1365	0C2D
Bus 2R	0617	Null	12AB	12CB	Null	Null	19CB	1365	0C2D
Bus 3L	0618	Null	12AC	12CC	Null	Null	19CC	1366	0C2E
Bus 3R	0618	Null	12AC	12CD	Null	Null	19CC	1366	0C2E
Bus 4L	0619	Null	12AD	12CE	Null	Null	19CD	1367	0C2F
Bus 4R	0619	Null	12AD	12CF	Null	Null	19CD	1367	0C2F
Bus 5L	061A	Null	12AE	12D0	Null	Null	19CE	1368	0C30
Bus 5R	061A	Null	12AE	12D1	Null	Null	19CE	1368	0C30
Bus 6L	061B	Null	12AF	12D2	Null	Null	19CF	1369	0C31
Bus 6R	061B	Null	12AF	12D3	Null	Null	19CF	1369	0C31
Bus 7L	061C	Null	12B0	12D4	Null	Null	19D0	136A	0C32
Bus 7R	061C	Null	12B0	12D5	Null	Null	19D0	136A	0C32
Bus 8L	061D	Null	12B1	12D6	Null	Null	19D1	136B	0C33
Bus 8R	061D	Null	12B1	12D7	Null	Null	19D1	136B	0C33
Stereo L	0632	Null	12C6	12E4	Null	Null	19E6	1380	0C48
Stereo L	0632	Null	12C6	12E5	Null	Null	19E6	1380	0C48
Stereo R	0633	Null	12C7	1302	Null	Null	19E7	1381	0C49
Stereo R	0633	Null	12C7	1303	Null	Null	19E7	1381	0C49
Buses to Mix.....									
	On	Level							
Bus 1	0B64	05AE							
Bus 2	0B65	05AF							
Bus 3	0B66	05B0							
Bus 4	0B67	05B1							
Bus 5	0B68	05B2							
Bus 6	0B69	05B3							
Bus 7	0B6A	05B4							
Bus 8	0B6B	05B5							